

ROKINON® **F**



35mm F1.8 Auto Focus SONY E MOUNT Instruction Manual

Thank you for purchasing the Rokinon Compact AF 35mm F1.8 Full Frame prime lens. This lens is specifically designed to provide optimal quality Full Frame, and APS-C still images and video with all Sony E mount cameras.

Features

- With an inconspicuous size, a slightly wide angle of view, and an 11.4" minimum focusing distance, it is perfect for, travel, stealthy street shooting, and landscapes.
- The fast F1.8 maximum aperture with a 9 blade iris provide low light performance, and smooth circular bokeh effects.
- Autofocusing utilizes a LSM (Linear Stepless Motor) for quiet, and smooth focus that is especially important when recording video.

- Ten elements in eight groups, including two Aspherical, and two High Refractive Index special elements plus Ultra Multi Coating, combine to maximize image quality, and contrast even at wide open aperture.

- The Custom Switch enables the Control Ring to function as a control for manually adjusting focus or aperture. Additional functions are being developed that can be added via firmware updates.

- The IF (Internal Focusing) design prevents both changes in length and front element rotation. This enables the easy use of polarizers and other filters that require precise positioning.

- The refined metal chassis offers excellent durability, and is weather sealed to help protect against dust and moisture.

Cleaning

- It is extremely important before cleaning to dust off the lens surface using a lens blower or a soft brush to remove any foreign particles or grit that could scratch the lens.
- For stubborn spots, use only one or two small drops of a reputable lens cleaner on a microfiber cloth, and gently wipe the lens in a circular motion.

DO NOT USE AN ORGANIC SOLVENT SUCH AS PAINT THINNER, ALCOHOL, OR BENZENE.

Cautions

To maintain your safety and prevent damage to the lens, please fully familiarize yourself with the following:

- Do not look directly at the sun through the lens as It may seriously impair your vision.
- Do not to apply excessive force when attaching the lens to the camera as it may cause damage to the lens or your camera.
- The lens is a precision optical product, so dropping or excessive impact may cause product failure.
- Attach or detach the lens only while the camera is turned off.
- Protect the lens from water, high humidity and excessive heat.

- Avoid subjecting the lens to drastic temperature changes such as moving from a very cold outdoors location to a warm indoor location. This can cause moisture in the air to condense inside and on the outside of the lens which can lead to failure or mold production. Before taking the lens indoors from a cold outdoors location, put the lens in a plastic bag or sealed camera bag and remove it only when the lens has warmed up to room temperature.

- Always store the lens with the lens cap on in a dry and well ventilated location out of direct sunlight. Direct sunlight passing through the lens could become concentrated enough to cause a fire.

Attaching/Detaching the Lens

- Align the index mark on the lens barrel with the index mark on the lens mount of the camera.
- Do not press the lens release button on the camera when mounting the lens.
- Insert the lens into the camera mount and rotate it clockwise until it "clicks" and locks into place. Do not insert the lens at an angle.
- Remove the front lens cap when you are ready to shoot.
- To detach the lens, first attach the front lens cap.
- While holding down the lens release button on the camera body, rotate the lens counterclockwise until it stops, and separate the lens from the body.
- Attach the rear lens cap.


Lens Hood

The supplied hood is designed specifically for the ROKINON AF 35mm F1.8 Compact lens for optimum effectiveness. It should be used at all times to help prevent contrast reducing flare, provide better contrast, and for added protection.

- To mount the hood, align the white index mark (dot) of the hood with the white hood index mark (dot) of the lens, and rotate the hood clockwise until you hear and feel it click into place.
- To remove the hood, grasp it firmly and turn counter- clockwise.

Using the Custom Switch

The Custom Switch enables the custom control ring to function either as a manual focus control (**Mode 1**) or as an aperture control (**Mode 2**).



- **MODE 1:** When the camera is set to **MF** or **DMF** the custom control ring can be utilized to manually adjust focus.

When the camera is set to **AF-S** (Single-Shot AF), **AF-C** (Continuous AF), or **AF-A** (Automatic AF) the custom control ring is disabled. Available auto focus modes will depend on your particular Sony model. For detailed information regarding available focus modes please refer to your camera's instruction manual.

- **MODE 2:** The custom control ring can be utilized to manually adjust the aperture when the camera is set to any available auto focus mode.

